

Картриджи IG для струйных принтеров и копиров

Картриджи IG для струйных принтеров CANON

Картридж	Цвет	Совместимость
CANON BCI-21	В	Canon BJC-2000/2100/4000/4100/300/4400 /4550/4650/ 5100 /5500/S-100; для МФУ MultiPass C20/C30/C50/C70/C75/C80;
CANON BCI-21	COLOR	для ФАКСОВ FAX-B180C/B210C/B215C/B230C
CANON BCI-21\24 (universal)	В	BCI-24 - Canon i-250/320/350/450/455/470/475/S-200/200X/300 /330Photo/Pixma IP-1000/1500/2000; для МФУ SmartBase MPC 190/200/200 Photo/360/370/390
CANON BCI-21\24 (universal)	COLOR	BCI-21 -2000/2100/4000/4100/4200/4300/4400/4550/4650/5100/5500/S-100; для МФУ MultiPass C20/C30/C50/C70/C75/C80; для ФАКСОВ FAX-B180C/B210C/B215C/B230C
CANON BCI-24	В	Canon i-250/320/350/450/455/470/475/S-200/200X/300 /330Photo /Pixma IP-1000/1500/2000; для МФУ SmartBase MPC 190/200/200 Photo/360/370/390
CANON BCI-24	COLOR	
CANON BCI-3eBk	В	Canon BJC-3000/6000/6100/6200/6500/ i-550/560/850/865/6500/S-400/450/4500/500/520/530/6300/600/630/750 для МФУ MultiPass C100/Pixma MP 750/760/780/SmartBase -MPC400/600F/MP-700 Photo/730Photo
CANON BCI-3eC	С	
CANON BCI-3eM	М	
CANON BCI-3eY	Y	
CANON BCI-3ePBk	PHOTO	Canon BJC-3000/6000/6100/6200/6500/S-400/450/4500/500 /520/530 /6300/600/630/750/Pixma IP 4200/4300/5000 для МФУ MultiPass C100
CANON BCI-3ePC	PHOTO CYAN	
CANON BCI-3ePM	PHOTO MAGENTA	
CANON BCI- 5\6Bk (universal)	В	BCI-5Bk - Canon BJC-8200 BCI-6BK - BJC-8200/ I-865/905/905D/950/965/990/9100/ 9950/S-800/820D/830D /900 /9000/PiXMA iP -3000/4000/4000R/5000/6000D/8500 для МФУ PiXMA MP750/760/780
CANON BCI-3\5\6C (universal)	С	BCI-3 Canon BJC-3000/6000/6100/6200/6500/ i-560/850/6500/S-400/450/4500/500/520/530/6300/600/630/750 для МФУ MultiPass C100/Pixma MP 750/760/780/SmartBase -MPC400/600F/MP-700 Photo/730Photo BCI-5 - Canon BJC-8200 BCI-6 -Canon BJC-8200/I-560/865/905/905D/950/965/990/9100/9950/S-800/820D/830D/900/9000/PiXMA iP -3000/4000/ 4000R/5000/6000D/8500 для МФУ PiXMA MP750/760/780
CANON BCI-3\5\6M (universal)	М	
CANON BCI-3\5\6Y (universal)	Y	
CANON BCI-6Bk	В	BJC-8200/ I-865/905/905D/950/965/9909100/9950/S-800/820D/830D/900/9000/ PiXMA iP -3000/4000/4000R/5000/6000D/8500 для МФУ PiXMA MP750/760/780
CANON BCI-6C	С	
CANON BCI-6M	М	
CANON BCI-6Y	Y	
CANON BCI-6PC	PHOTO CYAN	BJC-8200/ I-905/905D/950/965/9909100/9950/S-800/820D/830D/900/9000/ PiXMA iP - 6000D/8500
CANON BCI-6PM	PHOTO MAGENTA	
CANON BCI-6R	GREEN	BJC-990/9950/PiXMA iP - 8500
CANON BCI-6R	RED	
CANON CLI 8BK	В	PIXMA IP4200/4200Refurbished/5200/5200R/6600D PIXMA MP500/800/800R/830/950 PIXMA Pro9001
CANON CLI 8C	С	
CANON CLI 8M	М	
CANON CLI I 8Y	Y	

Картриджи IG для струйных принтеров Lexmark

Lexmark 0016	В	Lexmark Z 13/Z 23e/Z 33
Lexmark 00026	COLOR	Lexmark Color Jetprinter i3, Z13, Z23, Z25, Z33, Z35, Z515, Z600Series, X1100 All-In-One X7/X75/X83/X125/X1150/X2250. Compaq Ink Jet Printers IJ650 Series

Картриджи IG для струйных принтеров HP

Картридж	Цвет	Совместимость
HP DJ 51626A (№ 26)	B	Hewlett-Packard DJ 400/400L/420C/500/510/520/540/550C/560C/900 series/ OfficeJet 300/330/3350/LX/350C
HP DJ 51629A (№ 29)	B	Hewlett-Packard DJ 600/600C/660/670/690C/695C/DW - 310/320
HP DJ 51645A (№ 45)	B	Hewlett-Packard DJ 710C/720C/722C/815C/820C /850C /870C/880C /890C/895C/ 930/CM/950 /959C /960C/970C /980C/990C/995C/1100C /1120C /1125C /1180C /1220/1280/1600/6122/6127/9300/OfficeJet 4105 /4110/4212/4215/4219/4252/4255 /6110/5505/5510/5515/5605/5610/
HP DJ C1823D (№ 23)	COLOR	Hewlett-Packard DJ 710C/720C/722C/810/815C/880C/890C/ 895Cxi/ 1120C/1125C
HP DJ C6578D (№ 78)	COLOR	Hewlett-Packard DJ 450C/916C/920C/930C/CM /940C/950C/959C /960C/970C/980C/990C/995C/1180C/1220C/1280/3810/3816/3820/3822/6122/6127/9300 PSC 2100/2200 PS 7xxx/ Color Copier- 290/310 /OfficeJet 6213/7213/7313/7413/
HP DJ C6614D (№ 20)	B	Hewlett-Packard DJ 610C/615C/640C/656C/Fax 925xi/1020
HP DJ C6615D (№ 15)	B	Hewlett-Packard DJ 810C/816C/825C/840C/843C /845C/916C/920C /940C/ Color Copier 310/3810/3816/3820/3822 OfficeJet 5110/v30/v40/v45/PSC500/750/950 /Fax1230
HP DJ C6656A (№ 56)	B	Hewlett-Packard DJ 450C/5550/PhSm 7150/7260/7345/7350/7450/7459 /7550/7655 /7600/7755/7760/7762/7960/7960GP/7762/7960/7960GP/PSC 1100/120 /1210/1213/ 1215/1217/1219/1310/1311/1312/1315/1315S/1317/1340/1350/1355/2105/2108/2110/ 2115/2171/2175/2179/2210/2410/2510
HP DJ C6657A	COLOR	Hewlett-Packard DJ 450Ci/450CB/450WBT/5145/5150/5151/5550/5552/5650/5652 /5655/5850/9650/6970/9680GP/Digital Copier 410/OfficeJet 4105/4110/4212/4215/ 4219/4252/4255/6110/5505/5510/5515/Photo Smart 100/130/230/145/245/ 7150/7260/7345/7350/7450/7459/7550/7655/7660/7755/7760/7762/7960/7960GP/PSC 1100/1200 /1210 /1213/1215/1217/1219/1310 /1311/1312 /1315/1317/1340/ 1350/1355/2105/2108/2110/2115/2171/5475/2179/2210/2410/2510
HP DJ C8727A (№ 27)	B	Hewlett-Packard DJ 3320/3325/3420/3425 /3520/3535 /3550/3745 /3645/3647/3650/3845/5650/5652/5655/5850/OfficeJet 4212/4215 /4219/4252/4255/6110/4315/4355/5605/5610/PSC 1210/1213 /1215 /1217/1219/1311/1312/1315/1317
HP DJ C8728A (№ 28)	COLOR	
HP DJ 8721	B	HP Photosmart 3213/ 3313/ 8253/ 8200
HP DJ 8771	C	
HP DJ 8772	M	
HP DJ 8773	Y	
HP DJ 8774PC	PHOTO CYAN	
HP DJ 8775PM	PHOTO MAGENTA	

Картриджи IG для струйных принтеров Brother

Brother CB 900	B	FAX1840C, FAX1940CN, FAX2440C, MFC210C, MFC420CN, MFC620CN, MFC3240C, MFC3340CN, MFC5440CN and MFC5840CN, Brother Fax - 2440C/1840/1940 / DCP -110C
	C/M/Y	Brother Fax - 2440C/1840/1940 / DCP -110C
Brother LC1000	B	Brother MFC-240, MFC-440CN, MFC-5860CN, MFC-665CW, DCP-130C
	C	
	M	
	Y	

Картриджи для струйных принтеров Epson

EPSON T003011	B	Epson Stylus Color 900/980
EPSON T005011	COLOR	
EPSON T007401	B	Epson Stylus Photo 790/870/875/890/895/900/915/1270/1290/1290S
EPSON T008401	COLOR	Epson Stylus Photo 790/870/875/890/895/915
EPSON T009401	COLOR	Epson Stylus Photo - 900/1270/1290/1290S
EPSON T013401	B	Epson Stylus Color 480/580/3000/C20SX/C 20UX/C40 SX/C40 UX
EPSON T014401	COLOR	
EPSON T017401	B	Epson Stylus Color 680/680T/685/777/777i; 1000ICS
EPSON T018401	COLOR	Epson Stylus Color 680/680T/685/777/777i
EPSON T019401	B	Epson Stylus Color 880/880i
EPSON T020401	COLOR	
EPSON T026401	B	Epson Stylus Photo 810/820/925/830/830U/935/ PM-810/730C/ 830C/850PT
EPSON T027401	COLOR	Epson Stylus Photo 810/820/925/830/830U/935/ PM-810/730C/830C/850PT/C50
EPSON T028401	B	Epson Stylus C60/C61/CX3100
EPSON T029401	COLOR	
EPSON T032140	B	Epson Stylus Photo C70/C80/C82/CX5200
EPSON T032240	C	
EPSON T032340	M	
EPSON T032440	Y	
EPSON T033140	B	Epson Stylus Photo 950/960
EPSON T033240	C	
EPSON T033340E	M	
EPSON T033440	Y	
EPSON T033540	LIGHT CYAN	
EPSON T033640	LIGHT MAGENTA	
EPSON T036140	B	Epson Stylus C42/C42+/C42S/C42SX/ C42UX/C44 /C44UX/C46
EPSON T037040	COLOR	
EPSON T03814A	B	Epson Stylus C41/C41SX/C41UX/C43/C43UX/C43SX/C45/CX1500
EPSON T03904	COLOR	
EPSON T040140	B	Epson Stylus C62/CX3200
EPSON T041040	COLOR	
EPSON T042240	C	Epson Stylus C82/C82N/C82WN/CX5100 /CX5200 /CX5300 /CX5400
EPSON T042340	M	Epson Stylus C82/C82N/C82WN/CX5100 /CX5200 /CX5300 /CX5401
EPSON T042440	Y	Epson Stylus C82/C82N/C82WN/CX5100 /CX5200 /CX5300 /CX5402
EPSON T043140	B	Epson Stylus C84/C84 Photo edition/C86/CX6400
EPSON T044140	B	Epson Stylus C84/C84 Photo edition/C86/CX6401
EPSON T044240	C	Epson Stylus C84/C84 Photo edition/C86/CX6400
EPSON T044340	M	
EPSON T044440	Y	
EPSON T046140	B	Epson Stylus C63/C65/C83/C85/CX3500/CX450 /CX6300/CX6500
EPSON T047240	C	Epson Stylus C63/C65/C83/C85/CX3500/CX450 /CX6300/CX6501
EPSON T047340	M	Epson Stylus C63/C65/C83/C85/CX3500/CX450 /CX6300/CX6502
EPSON T047440	Y	Epson Stylus C63/C65/C83/C85/CX3500/CX450 /CX6300/CX6503
EPSON T048140	B	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX620
EPSON T048240	C	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX621
EPSON T048340	M	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX622
EPSON T048440	Y	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX623
EPSON T048540	LIGHT CYAN	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX624
EPSON T048640	LIGHT MAGENTA	Epson Stylus Photo R200/R300/R300M/R320/RX500 RX600/RX625

Картриджи для струйных принтеров Epson

EPSON T050140 (SO 20206/08)	B	Epson Stylus Color 400/440/480/500/600/640/Photo Stylus Color 480/580/660/670
EPSON T051140 (SO20108/20189)	B	Epson Stylus Color 740/760/800/850/860/1160 /1520/Scan 2000/2500
EPSON T052040 (SO 20089/191)	COLOR	Epson Stylus Color 400/440/460/600/640/ 660/670 /740/760/800/850/860/1160/1520; C20/C20UX /C20SX /C40/C40UX/ C40S/ C40SX; SCAN 2000/2500/2500Pro
EPSON T053040 (SO 20193)	COLOR	Epson Stylus Photo/Photo EX/EX2/EX3/Photo 700/710/ 720/750/750 MILLENNIUM; PM-600C/670C/680C/700C/ 750C/ 770C/2000C/IP-100/
EPSON T054040	GLOSS	Epson Stylus Photo R800/R800M/R1800
EPSON T054140	PHOTO	
EPSON T054240	C	
EPSON T054340	M	
EPSON T054440	Y	
EPSON T054740	RED	
EPSON T054840	MATTE	
EPSON T054940	BLUE	
EPSON T055140	B	
EPSON T055240	C	
EPSON T055340	M	
EPSON T055440	Y	
EPSON T573	6 color	Epson PictureMate 100
EPSON T557	6 color	Epson PictureMate PictureMate 500
EPSON T063140	B	Epson Stylus C67/C87/CX3700/CX4100/CX4700
EPSON T063240	C	
EPSON T063340	M	
EPSON T063440	Y	
EPSON T066	B	Epson Stylus C48
EPSON T067	COLOR	
EPSON T0731	B	Epson Stylus CX3900/CX3905/CX4900/cx4905/ CX5900/CX6900F, Epson Stylus C79
EPSON T0732	C	
EPSON T0733	M	
EPSON T0734	Y	
EPSON T0821	B	Epson Stylus R270/R390/RX590
EPSON T0822	C	
EPSON T0823	M	
EPSON T0824	Y	
EPSON T0825	LIGHT CYAN	
EPSON T0826	LIGHT MAGENTA	
EPSON T0921	B	Epson Stylus C91/CX4300
EPSON T0922	C	
EPSON T0923	M	
EPSON T0924	Y	